

1935 THRU 48 LOCK PARTS CHART

Name	Group	Part	1935 thru 48	IGN. LOCK	DOOR HANDLE (Less Cyl. and Key)	DOOR PILLAR LOCK	REAR COMPT. SEDANS				REAR COMPT. COUPE				TIRE COMPT.		
				1936	1937	1938	1939-40, 25	1939-40, 26-28 exc. Conv., 1941 thru 48	1940-29, 1941 thru 48	1936-37-38	1939-40, 26-28	1940-29	1941 exc. 24-29, 1942	1941, 24-29	1946 thru 48	1937-38 Conv. Cpe.	
SHAFT.....	10.554	603166			X	X											
	12.252	601266										X					
	12.252	602553					X	/			X					X	
	12.252	1394710					X	X				X	X	X			
	10.554	605325				X	X										
	12.252	1393109							X	X				X	X		
	12.252	607073									X					X	
CASE.....	10.552	601264		X	X	X	X										
	12.249	601274						X	X	X	X	X	X	X	X	X	X
	10.552	1394712				R	R										
	10.552	1394713				L	L										
TENSION SPRING.....	10.551	4043224		X	X	X	X		X	X	X	X	X	X	X	X	X
SPRING & WASHER PKG.....	10.551	1394715				X	X										
RETAINER SPRING.....	10.551	4131755				X	X										
RETAINER SPRING.....	12.249	4146973									X					X	
CYLINDER.....	10.550	601263		X	X	X	X										
	12.248	601263						X	X	X	X	X	X	X	X	X	
	10.550	1394992				L	L										
	10.550	1394993				R	R										
	2.188	1097319	X														
	12.248	607162									X					X	
KEY.....	2.187	3694624	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
	2.187	7002238						X	X	X	X	X	X	X	X	X	X
PAWL.....	10.531	4047332		X	X												
	10.531	4082053			X	X											
	12.254	4023959						X	X	X	X	X	X	X	X	X	
CYL. RETAINER PIN.....	10.551	4045949		X	X	X	X										
	12.248	4045949						X	X	X	X	X	X	X	X	X	

R—Used on R.H. side. L—Used on L.H. side.

1949 THRU 54 LOCK PARTS CHART

Name	Group	Part No.	IGN.	DOOR HANDLE	REAR	REAR	BACK														
			LOCK	(Less Cyl. & Keys)	COMPT.	COMPT.	DOOR														
			1949 thru 52	1953-54	1949—1st Type	1949-50—2nd Type on 1949	1951	1952	1953-54	1949—2507-08	1949—2511-27-27B-67 & 69	1950	1951	1952	1953-54	1949—Sdl.—1st Type	1949-50—2nd Type on 1949	1951	1952	1953-54	
BUTTON, handle (Rear door)	10.529	4151760			X	X	X	X	X												
CAP, push button	10.552	7001022			X											X					
		7002226				X											X				
		7003044					X	X	X										X	X	X
CASE AND SPRING	12.249	3692522								X	X										
CLIP, retainer		516497												X							
CYLINDER	12.248	513612								X	X										
		1097868										X	X	X	X						
	2.188	1097319	X																		
		1458180		X																	
CYLINDER KIT	10.550	3693969			X	X	X									X	X	X			
		3697875						X	X											X	X
KEY	2.187	3694624	X	X	X	X	X	X	X												
		7002238								X	X	X	X	X	X	X	X	X	X	X	X
PAWL	12.254	4167906								X	X										
PIN, cylinder ret.	12.248	4045949								X	X										
PLATE, retainer	12.249	514449											X								
RETAINER, push button spring	10.529	4168353			X	X	X	X	X												
RETAINER, handle	10.551	4561579			RF	RF	RF	RF													
		4561580			LF	LF	LF	LF													
	(2508)	4563235			RR	RR															
	(2508)	4563236			LR	LR															
	(2562 & 69)	4561579			RR	RR	RR	RR													
	(2562-69 & 71)	4561580			LR	LR	LR	LR								X	X		X	X	
	(2511-62-69-71)	4601481							X												
	(2511-62-69-71)	4601482							X												
	(2537-67)	4601975							X												
	(2537-67)	4601976							X												
RING, button sealing	10.529	4168356			X	X	X	X	X												
	Round head	10.552	4584716			X	X	X	X							X					
SHAFT	Spade head	10.554	7001075		X																
	Spade head		7001058													X					
	Round head		7001048														X				
	Round head		7003040			X	X	X	X												
			7003042																	X	X
	12.252	3692541								X											
		513580								X											
		7003048									X	X	X	X							
SLEEVE, push button	10.552	7001021			X											X					
		7002210				X											X				
		7003043					X	X	X									X	X	X	
SPRING, push button	10.529	4173131			X	X	X	X	X												
WASHER, cyl. ret.	10.552	7001024			X											X					
		7001043				X	X	X	X								X	X	X	X	
WASHER, push button outside	Front	10.529	4168349			X	X	X	X												
	Back		4168349														X	X	X	X	
WASHER, ret. outside	Rear	10.529	4168350			X															
	Rear		4173132				X	X	X	X											
WASHER, spring stop	10.529	4173130			X	X	X	X	X												

RF—Used on RH side front.

RR—Used on RH side rear.

LF—Used on LH side front.

LR—Used on LH side rear.